


Ermetika[®]
INSIDE WALLS





ISTRUZIONE MONTAGGIO - SETUP INSTRUCTION
INSTRUCTION MONTAGE- INSTRUCCIONES DE MONTAJE


Staffa di giunzione per anta doppia - Junction kit for double door
Bride de jonction - Montaje grapa de union

CONTENUTO KIT | CONTENTS


Dotazione - Standard equipment - Equipement standard - Equipo standard




Attrezzatura - Tools - Outils - Herrajes



Panoramica - Overall view - Vue d' ensemble - General




1.




SX / LEFT

DX / RIGHT



2.



Subject to misprints, errors and technical modifications.
All dimensione are in mm

WATCH OUR
You Tube
VIDEOS HERE



T. +39 (0)883535781



info@ermetika.it



www.ermetika.it